

VALVE PARTS




Figure 3-23. Valves seal the combustion chamber to control the flow of air-fuel mixture into the cylinder and exhaust gases out of the cylinder.